Everest Series Recorder-Workstation

QUICK START GUIDE

Supports Everest X, Everest and EV2 Series Recorder-Workstation

System Software Version 2.9

- 1. INTRODUCTION
- 2. GETTING STARTED
- 3. CONTROL PANEL & BUTTONS
- 4. USING THE EVEREST SERIES RECORDER-WORKSTATION
- 5. SETTING UP THE DISPLAY APPEARANCE
- 6. AMPLIFIER SETTINGS
- 7. SAMPLE EXERCISES
- 8. POWERING DOWN

APPENDIX A SIGNAL INPUT WIRING

Astro-Med, Inc.

Astro-Med Industrial Park, 600 East Greenwich Ave. West Warwick, RI 02893 Toll-Free Phone: 877-867-9783 Phone: 401-828-4000 Fax: 401-822-2430 email: mtgroup@astromed.com

Part Number: 22834482 (v 2.9)

May, 2009

More Application, Information, and Pricing available at

Click to go www.TestWorld.com

sales@testworld.com

1-855-200-TEST (8378)

TestWorld 250 Technology Way

Rocklin, CA 95765

1. INTRODUCTION

Thank you for choosing the Astro-Med Everest Series Recorder-Workstation. Both analog and digital input signals are accepted through a variety of interface options and can be networked to other systems if desired. Signals can be displayed on the monitor, printed to paper, or stored to disk.

This Quick Start Guide is designed to allow you to become familiar with the basic Everest Series Recorder-Workstation operations in a minimal amount of time. We encourage you to review the manual as well as the extensive On-Line Help within the Recorder-Workstation.

2. GETTING STARTED

Voltage Verification: The Everest Series Recorder-Workstation has an auto-sensing power supply that operates on 115 / 230 VAC. Power draw is 300 Watts typical (560 Watts maximum).

Connect Video Cable: Use the supplied video cable to connect the Video Output to the Video Input on the rear panel of the Everest. (The Everest X and the EV2 do not have this video cable).

Connect AC Power Cord: Connect AC power cord to the rear panel, then to an outlet.

Load Chart Paper (Z-fold): Pull the door on the front of the unit forward to open the paper chamber. Be sure the arrows stamped on the paper are pointing toward the inside of the chamber. Insert the top sheet beneath the drive roller (where indicated by the down arrows printed on the unit, and the message INSERT PAPER HERE). Gently feed paper until it exits above the drive roller. Allow paper to exit above the paper chamber door.

Turn On: When you turn on the Recorder-Workstation, the display will show various initialization screens and then load in the last setup it had before it was powered down.

Important: When you power down, a green LED next to the power switch will flicker for a few moments as the unit powers down. You **must** allow the unit to complete the power down sequence before turning it back on. See section 8 for more details.

Signal Input: The SM2 / SM3 and SM2D / SM3D are eight-channel analog input modules. Up to four modules can be installed for up to 32 analog channels or recording. Signal Leads are not provided. The SM2 and SM3 use BNC input connectors for each channel. The SM2D and SM3D use a 25-pin D-shell connector for each group of eight channels. See Appendix A for wiring information. For digital data input, the optional DI-EV Ethernet Digital Input Option or the optional DM1 High-Speed Digital Input Module is available.

Display: The Recorder-Workstation uses a large Touchscreen display. The display is divided into two main areas, the Waveform Display Area and the Control Panel.

Waveform Display Area: shows the waveform signals typically drawn onto grid patterns. Additional information about the signals is available in this area such as pen movement and channel signal range values (channel limits). In addition, a bitmap image can be superimposed over the waveforms to provide the user with additional information.

Control Panel: The control panel provides System Information as well as buttons to initiate action. The System Information area shows the chart speed, day, date, time as well as progress of certain functions such as disk access, data capture, etc. The System Information area is located at the top of the control panel. More information on using buttons and the control panel are in separate sections below.

Help: Access the online help through the Home Menu.

3. CONTROL PANEL & BUTTONS



The control panel is the toolbar across the top of the screen that allows access to system functions using icon-based buttons and menus. The control panel is the primary control interface. Buttons on the control panel may cause action, load files, or open menus. The control panel is located at the top of the display.

The control panel can be customized to arrange buttons suitable for particular operations. Once designed, custom control panels can be saved to disk and recalled as desired.

Whether or not a function is represented as a button on the control panel, access to all functions is available through the Home Menu.



When the Home Menu button is pressed, the 12 system functions become available:



Commonly Used Buttons

Over 60 buttons in up to fours rows can be displayed. The control panel can be customized to add or remove buttons. There are various types of buttons:

Home Menu	The Home Menu button allows access to the 12 main system functions.
Setup	Setup buttons are shortcuts to the 12 main system functions. They resemble a book. They toggle between open and closed to indicate activity.
Configuration	Configuration buttons load configuration files. They resemble folders. They are color-coded based on type.
Action	Action buttons cause immediate action. Some buttons appear pushed in or out to indicate their present state of action.
Help	Provides information about the buttons. When this button is active (depressed), pressing any other button on the control panel will give a short description of that button.
Context Help	Provides information about the function being used.
Apply	Allows you to make changes and observe their results without making permanent changes.
Exit	Cancels any changes and exits the menu.
ОК	Applies changes and exit the menu.



















4. USING THE EVEREST SERIES RECORDER-WORKSTATION

There are five available modes of operation. Some of these modes are optional, such as Virtual Chart. Others require specific hardware, such as data capture for the signal input modules.

Realtime Recording: Traditional recording of waveform signals to the display and/or chart paper. This is a standard feature.

Realtime Recording with Highlight Mode: This is similar to Realtime Recording described above, except that chart printing is delayed to allow annotation to be added. This is a convenient feature to quickly mark a point of interest on the display and have it print on the chart paper. Preprogrammed text can quickly be selected. This is a standard feature.

Realtime Recording with Waveform History Mode: A Waveform History is a data record that contains all the information required to reproduce a section of the chart. This includes recording of signals, events, grid lines, time marks and highlight comments. While history files are being viewed, the display of realtime data is not obstructed. Waveform History is a standard feature.

Virtual Chart Recording: Saves realtime data to a dedicated disk drive. Data saved includes all data generated, including changes to signal settings and chart speeds. The resulting record provides a means for performing data review and testing of historical data. Virtual Chart is an option.

Data Capture Recording: Data capture allows capture of high-speed transient waveforms. Data capture happens in the background and does not interrupt realtime recording. Data capture for the signal input modules must be purchased at time of order.

5. SETTING UP THE DISPLAY APPEARANCE

You have total control over the appearance of the display and chart layout. Set individual channel widths, channel location, grids on or off. Suppress or enable waveform printing as well as vary the waveform trace thickness. Further, you can overlap some or all of the channels.

The Chart / Display menu can be accessed through the Home Menu. You can select from Basic 8, 16, or 32 channels from the menu. You can also use the Chart / Display Wizard or the Advanced Chart / Display Setup:

Chart / Display Wizard: (quick method for setting up simpler charts)

Choose the number of channels, events and text buffers

Select on of the four formats (individual or overlap, location of events or text buffers)

Advanced Chart / Display Setup: (total customization of the chart and display)

Define layout and sizes of grids

Choose locations of events and text buffers

Choose display items such as colors, pen styles, labels, etc.

Choose chart items such as timing marks, trace thickness, etc.

Save the Chart / Display settings as View files

6. AMPLIFIER SETTINGS

Each channel has unique amplifier settings. In addition to setting the span for each channel, you can also adjust the zero position. Further, user scaling is supported so that your channels can report their value in terms of Engineering Units. For convenience, amplifier settings can be copied to other channels.

7. SAMPLE EXERCISES

Five sample exercises are included in this section to make use of the five different recording modes that are available. Most of the recording modes can be used with each other at the same time to maximize flexibility. Some of the recording modes are optional, and that will be noted with the exercise.

Items needed: Everest Series Recorder-Workstation with a minimum of one SM2, SM3, SM3D, or SM3D signal input module. Waveform Signal Generator to produce at Sine Wave, 1 Hz with a +/- 1 Volt amplitude. Signal input leads.

7a. Realtime Recording

Realtime Recording is traditional waveform signal plotting to the display and/or chart paper. This is a standard feature. A channel will be set up so that when there is no signal, the waveform trace will be in the center of the grid. When the sine wave is applied, the waveform trace will be shown symmetrically within the grid.

ACTION

HOW TO

Control Panel Configuration Confirm that your Control Panel has the following buttons:



If any of the buttons are not shown, use the steps on the next page to add them.

Helpful Hints when working with Control Panels:

1. Group similar functions together on the control panel when you add buttons to make operation more convenient.

2. If you make an error, you can delete the button by highlighting it and press the Clear button.

3. When you try to add duplicate keys to the control panel, they are removed when you press OK and a warning box advises you that this will happen.

4. You can relocate buttons on the control panel by dragging and dropping them to a new location.

continued \rightarrow

	Trigger			Spee	ed		Chart/Dis	play Control		Realtin	ne Control			Favorites	
	Capture	6		Review			Signals			Help			Miscellaneous		
1	video Doci	king				11110									
1 m/s	5 mm/s	25 mm/s	50 mm/s	100 mm/s	200 mm/s			1						?	?
	_	_			_	_		_	_	_			_	_	
														X	
											7	7		X	0

Everest Series Recorder-Workstation Control Panel Modification

To add Set Speed button	Choose Home Menu button >> Custom Control Panel >> Make New Panel Press one of the empty cells to highlight where the button will be placed Press Speed Press mm/s. A keypad pops up Press the digit(s) for the speed you want Press [OK] To add another speed button, skip the next step and highlight where it will be placed. Press [OK] to accept the control panel
To add Run / Halt Chart button	Choose Home Menu button >> Custom Control Panel >> Make New Panel Press one of the empty cells to highlight where the button will be placed Press Chart / Display Control Press Chart Run / Halt To add another button, skip the next step and highlight where it will be placed. Press [OK] to accept the control panel
To add Run / Freeze Monitor button	Choose Home Menu button >> Custom Control Panel >> Make New Panel Press one of the empty cells to highlight where the button will be placed Press Chart / Display Control Press Monitor Run / Freeze To add another button, skip the next step and highlight where it will be placed. Press [OK] to accept the control panel
To add Context Help button	Choose Home Menu button >> Custom Control Panel >> Make New Panel Press one of the empty cells to highlight where the button will be placed Press Help Press Context Help To add another button, skip the next step and highlight where it will be placed. Press [OK] to accept the control panel
To add Help button	Choose Home Menu button >> Custom Control Panel >> Make New Panel Press one of the empty cells to highlight where the button will be placed Press Help Press Icon Help Press [OK] to accept the control panel
Run the basic 8- channel grid pattern	Press the Home Menu button Press Chart / Display Press Basic 8 Channel
Input Signal	Input sine wave signal, 1 Hz, +/- 1 Volt amplitude into Channel 1 (Waveform A01)











Halt the display	Press the Monitor Run / Freeze button
------------------	---------------------------------------

Run the display	Press the Monitor Run / Freeze button
Run the chart paper	Press the Run / Halt Chart button

Change speed to	Press the 50 mm/sec button
50 mm/sec	
Change speed to 5 mm/sec	Press the 5 mm/sec button
Change speed to	Press the Home Menu button
14 mm/sec	Press Realtime Setup
	At the bottom of the Realtime Setup menu is a box with the number
	for the current speed.
	Press the number box. A keypad pops up. Press the digits "14", then [OK]
	Press [OK]

Stop the chart paper

Press the Run / Halt Chart button

Set up the signal input for channel 1

abel	S	pan		Center		Units		Hardw	are
01 - Waveform A01	40	0.000		0.000		V		SE, 40	VC
02 - Waveform A02	40	0.000		0.000		V		SE, 40	VC
03 - Waveform A03	40	0.000		0.000		V		SE, 40	vc
04 - Waveform A04	40	0.000		0.000		V		SE, 40	VC
05 - Waveform A05	40	0.000		0.000		V		SE, 40	vc
06 - Waveform A06	40	000		0.000		V		SE, 40	VC
07 - Waveform A07	40	000		0.000		V		SE, 40	vc
08 - Waveform A08	40	000		0.000		V		SE, 40	VC
301 - Waveform B01	40	000		0.000		V		SE, 40	vc
302 - Waveform B02	40	000.0		0.000		V		SE. 40	vc
303 - Waveform B03	40	000		0.000		V		SE, 40	VC
304 - Waveform B04	40	000		0.000		V		SE. 40	VC
305 - Waveform B05	40	000		0.000		V		SE. 40	V
DOG Mountarm DOG	40	000		0.000		11		OF AC	11/
	Span	Center	Units	Hardware	Filter	Ground	Low Alarm	High Alarm	Audio Alarm

Everest Series Recorder-Workstation Amplifier Setup

Set channel 1 to be +/- 2.5 Volts full scale	Press the Home Menu button Press Signal Inputs Highlight A01 – Waveform A01 (Channel #1) Press the Span button Press the digit "5", then [OK]
Set zero in center of the channel	Toggle the Show Bottom / Center Value button so that the Center is shown Press the Center button Press the digit " 0 ", then [OK] Press [OK] to exit the Amp Setup menu





Apply signal Input sine wave into Channel #1 (Waveform A01)







7b. Realtime Recording with Highlight Mode

This is similar to Realtime Recording used in the exercise above, except that chart printing is delayed by one screen's worth to allow annotation to be added. This is a convenient feature to quickly mark a point of interest on the display and have it print on the chart paper. Preprogrammed text can quickly be selected. This is a standard feature.

In this exercise, we will modify the Control Panel to give us quick access to buttons used with the Hightlight Mode. Continue with the two-grid pattern and channel setup made with the Realtime Recording exercise above.

ACTION

Control Panel

Configuration

Confirm that your Control Panel has the following buttons for Highlight Mode:



HOW TO

If any of the buttons are not shown, use the steps on the next page to add them. See "Helpful Hints when working with Control Panels" on Page 6 of this guide.

To add Set Highlight button	Choose Home Menu button >> Custom Control Panel >> Make New Panel Press one of the empty cells to highlight where the button will be placed Press Realtime Control Press Set Hightlight <i>To add another button, skip the next step and highlight where it will be placed.</i> Press [OK] to accept the control panel
To add Highlight Undo button	Choose Home Menu button >> Custom Control Panel >> Make New Panel Press one of the empty cells to highlight where the button will be placed Press Realtime Control Press Hightlight Undo <i>To add another button, skip the next step and highlight where it will be placed.</i> Press [OK] to accept the control panel
To add Local Mark button	Choose Home Menu button >> Custom Control Panel >> Make New Panel Press one of the empty cells to highlight where the button will be placed Press Chart / Display Control Press Local Mark To add another button, skip the next step and highlight where it will be placed. Press [OK] to accept the control panel
To add Global Mark button	Choose Home Menu button >> Custom Control Panel >> Make New Panel Press one of the empty cells to highlight where the button will be placed Press Chart / Display Control Press Global Mark Press [OK] to accept the control panel
Enable and Set Up Highlight Mode	 Press the Home Menu button Press Realtime Setup Press the gray button next to Highlight (*Chart Delay*) (A green checkmark appears) Press Setup button Turn on the Highlight State, Highlight Text State, Chart Delay Indicator. 26 keys available for preprogrammed text, allowing for commonly used text to be printed quickly on the display and chart. Some keys may already be programmed. Press an undefined (blank) key. Press the Key Text box (A keyboard pops up) Type in the word BEGIN Note: You can use upper and lower case letters. There is a clear button to erase text. Press [OK] Press the Key Definition box (A keyboard pops up) Type in the phrase Start of our Test Press [OK] Press [OK] to exit Highlight Setup Press [OK] to exit Realtime Setup
Input Signal	Input sine wave signal, 1 Hz, +/- 1 Volt amplitude into Channel 1 (Waveform A01)
Set speed to 1 mm/sec	Press the 1 mm/sec button
Confirm Highlight Mode is active	<i>The Highlight Mode button should show an indentation to indicate that the mode is active. If not indented, press the button.</i>
Run the chart paper	Press the Run / Halt Chart button
Add a Highlight	Press anywhere on the display above the [*** Chart Start ***] banner <i>A line is drawn across the display and a window pops up showing the 26 text keys.</i> Press the ABC key to toggle between the text keys and the letter keys. Press the ABC key until the window shows the 26 text keys. Press the BEGIN text key you created earlier followed by the carriage return <i>The highlight will travel down the screen and when it reaches the bottom, it will print</i> <i>on the chart paper. Notice the text on the right side of the chart.</i>







continued \rightarrow

Enter your name as a Highlight	Press anywhere on the display above the [*** Chart Start ***] banner Press the ABC key until the window shows the 26 letter keys. Type in your name followed by the carriage return.	
Print Full Page Marks	Press the Local Mark button A line is drawn on the display and on the chart when it prints. The global mark button will print a line on all Recorder-Workstations on the network.	→
Change Speed to 5 mm/sec	Press the 5 mm/sec button	
Stop the Chart	Press the Run / Halt Chart button A ***Chart Stop*** yellow indicator is drawn on the display and follows down to the bottom as the chart continues to print. When the indicator is at the bottom of the display, the paper will stop. Wait until the chart stops before going to the next step.	
Exit Highlight Mode	Press the Home Menu button Press Realtime Setup Press the button next to Highlight (*Chart Delay*) <i>The green checkmark disappears</i> . Press [OK]	
	This completes the second exercise, Realtime Recording with Highlight Mode.	

7c. Realtime Recording with Waveform History Mode

A Waveform History is a data record that contains all the information required to reproduce a section of the chart. This includes recording of signals, events, grid lines, time marks and highlight comments. The full bandwidth of history file signals is preserved. Once captured, Waveform Histories are viewed on their own display window, separate from signals being displayed in realtime. While history files are being viewed, the display of realtime data is not obstructed. Waveform History is a standard feature.

Continue with the two-grid pattern and channel setup made with the Realtime Recording exercise above.

ACTION

Control Panel Configuration Confirm that your Control Panel has the following buttons for Waveform History Mode:



HOW TO

If any of the buttons are not shown, use the steps below to add them. See "Helpful Hints when working with Control Panels" on Page 6 of this guide.

To add History Save button

Choose Home Menu button >> Custom Control Panel >> Make New Panel Press one of the empty cells to highlight where the button will be placed Press Realtime Control Press History Save To add another button, skip the next step and highlight where it will be placed. Press [OK] to accept the control panel



To add Open Split Screen Review button	Choose Home Menu button >> Custom Control Panel >> Make New Panel Press one of the empty cells to highlight where the button will be placed Press Realtime Control Press Open Split Screen Review Press [OK] to accept the control panel	
Enable and Set Up Waveform History Mode	 Press the Home Menu button Press Realtime Setup Press the gray button next to History (A green checkmark appears) Press Setup button Press the Filename box (A keyboard pops up to enter the prefix name of our files) Type in the phrase Learning about Waveform History Press [OK] Note: You can use upper and lower case letters. There is a clear button to erase text Press the gray button next to "Auto Load File After Capture" (A green checkmark appears) Press [OK] to exit History Mode Setup Press [OK] to exit Realtime Setup 	
Set speed to 25 mm/sec	Press the 25 mm/sec button	
Input Signal	Input sine wave signal, 1 Hz, +/- 1 Volt amplitude into Channel 1 (Waveform A01)	
Perform Waveform History	Press the Save to History File button The status bar at the top will indicate progress of file saving.	
Review History File	Press the Open Split Screen Review button Highlight the top file name (newest file) Press [OK]	
Perform Amplitude Measurements	Select Amplitude in the Measurement pull-down box <i>A marker appears and the amplitude at that point is shown in the information box.</i> Use the up and down arrow keys to move the marker, or drag the marker	
Perform Time & Frequency Measurements	Select Time-Freq in the Measurement pull-down box Another marker appears and the time and frequency between markers is shown. An active marker button allows you to move one or the other marker, or both together. Use the up and down arrow keys to move both markers independently and together.	
Scroll through the History File	The Waveform Trackbar shows the History file for quick access to points of interest. If you have markers active, the markers are shown in the trackbar. Press anywhere in the Waveform Trackbar to quickly move within the file. You can also drag your finger across the display to move about the waveform.	
Show All File	Press the Compress File to fit in window button The entire file is placed within the review window. Note the compression factor in the status information box.	100 %
Expand the File View	Press the More Functions button located to the left of the exit button <i>Additional functions are shown</i> . Press the Expand file by factor of 2 button several times and note the expansion / compression factor as you do so.	

View File Information	Press the File Information button Various details about the file are shown in the review window.	
Print Waveform History File Data	Press the Print History Data button, select Everest <i>Notice that the file information is printed and then the waveforms.</i>	ő
Exit Waveform History File Review	Press the \mathbf{X} located in the upper right hand corner of the review screen	
Exit Waveform History Mode	Press the Home Menu button Press Realtime Setup Press the button next to History <i>The green checkmark disappears.</i>	

7d. Virtual Chart Recording

Saves realtime data to a dedicated disk drive. Data saved includes all data generated, including changes to signal settings and chart speeds. The resulting record provides a means for performing data review and testing of historical data. Hard copies of Virtual Charts can be generated on-demand. Search tools and export functions for saving Virtual Chart data in a variety of formats. Virtual Chart is an option.

ACTION Check for Virtual Chart option

HOW TO

Press the **Home Menu** button Press **Help** Press **About** If you have Virtual Chart, the Virtual Chart Graphic is displayed to the left of the system information. **Press X** to exit the Help About window **Press X** to exit the Menu window

Continue with the two-grid pattern and channel setup made with the Realtime Recording exercise above.

ACTION Control Panel Configuration

Confirm that your Control Panel has the following buttons for Virtual Chart:



HOW TO

If any of the buttons are not shown, use the steps below to add them. See "Helpful Hints when working with Control Panels" on Page 6 of this guide.

Add Start Virtual Chart button

Choose Home Menu button >> Custom Control Panel >> Make New Panel Press one of the empty cells to highlight where the button will be placed Press Realtime Control Press Start Virtual Chart To add another button, skip the next step and highlight where it will be placed. Press [OK] to accept the control panel



Add Abort Virtual Chart button	Choose Home Menu button >> Custom Control Panel >> Make New Panel Press one of the empty cells to highlight where the button will be placed Press Realtime Control Press Abort Virtual Chart To add another button, skip the next step and highlight where it will be placed. Press [OK] to accept the control panel		
Add Pause / Resume Virtual Chart button	Choose Home Menu button >> Custom Control Panel >> Make New Panel Press one of the empty cells to highlight where the button will be placed Press Realtime Control Press Pause / Resume Virtual Chart To add another button, skip the next step and highlight where it will be placed. Press [OK] to accept the control panel		
Add Review button	Choose Home Menu button >> Custom Control Panel >> Make New Panel Press one of the empty cells to highlight where the button will be placed Press Review Press Review Press [OK] to accept the control panel		
Set speed to 100 mm/sec	Press the 1 00mm/sec button		
Input Signal	Input sine wave signal, 1 Hz, +/- 1 Volt amplitude into Channel 1 (Waveform A01)		
Enable and Set Up Virtual Chart	 Press the Home Menu button Press Realtime Setup Press the gray button next to Virtual Chart (A green checkmark appears) Press Setup button Press the Filename box (A keyboard pops up to enter the prefix name of our files) Type in the phrase Learning about Virtual Chart Press [OK] Note: You can use upper and lower case letters. There is a clear button to erase text. Press the button next to *Limit Data Area Size (A green checkmark appears) Press the File Size box. A keypad pops up. Press the digits "7500", then [OK] Press [OK] to exit Virtual Chart Setup Press [OK] to exit Realtime Setup 		
Start Virtual Chart	Press the Start Virtual Chart button A window pops up to indicate status of the Virtual Chart		
Change signal frequency	Increase the frequency of the sine wave from 1 Hz to 10 Hz <i>Allow the signal to run for several seconds.</i>		
Remove signal	Turn off signal generator Leave generator off for several seconds.		
Apply signal	Turn on signal generator		
Change signal frequency	Decrease the frequency of the sine wave from 10 Hz to 1 Hz Continue the Virtual Chart unit it finishes <i>(don't Abort)</i> .		









Review Virtual Chart	Press the Review button Highlight the file just created Press [OK]	SHAP
Review the Virtual Chart on the display only	 Be sure the Chart Playback button does <u>not</u> have a red X through it. Press the Run / Pause Playback button The waveforms will scroll down the display. Notice the position indicator marker on the right hand side of the review window. Observe the increase in signal frequency, where the generator was turned off, and then back on. Wait for the playback to finish Drag the position indicator marker to return to the top of the file Press the Run / Pause Playback button to review the file again Slow down the playback by pressing the Decrease Playback Speed button Press the Run / Pause Playback button to pause the playback when you see the signal frequency change from 1 to 10 Hz. 	
Add a Bookmark	 A bookmark is a point of interest in the Virtual Chart file. Text can be added to note the details of interest. Press the Bookmark button Touch the display near the point where the signal frequency changed from 1 to 10 Hz. A line across the display will appear terminating with a green marker on the right hand side of the review window. Press the marker and choose Edit Bookmark Type in Frequency Change and press [OK] 	
Go to Bookmark	Drag the position indicator marker to return to the top of the file Press the Goto Specified Item button Press Bookmark button Press Goto Bookmark <i>The file position jumps to the place where we placed the bookmark.</i>	
Save part of the Virtual Chart file as a new file	Leave the display showing the bookmark. Repeat above step if bookmark not shown. Press the Archive Marker 1 button Press the display a few grid lines above the bookmark A line across the display will appear terminating with a yellow #1 marker on the right hand side of the review window. Press the Archive Marker 2 button Press the display a few grid lines below the bookmark A line across the display will appear terminating with a yellow #2 marker on the right hand side of the review window. Press the Archive Virtual Chart File button (The Archive Menu window opens). Be sure that Fixed Disk. Virtual Chart File and Save Between Markers are checked	
	 Press the Filename box. (A keyboard pops up to enter the prefix name of our files) Type in the phrase Signal Change Note: You can use upper and lower case letters. There is a clear button to erase text. Press [OK] Press the Archive File button in the bottom of the Archive Menu The file is saved to the system disk. Press [OK] Turn off Archive Marker 1 and Archive Marker 2 	

Perform Amplitude Measurements	Select Amplitude in the Measurement pull-down box <i>A marker appears and the amplitude at that point is shown in the information box.</i> Use the up and down arrow keys to move the marker a few grid lines below the bookmark created above			
Perform Time & Frequency Measurements	Select Time-Freq in the Measurement pull-down box Another marker appears and the time and frequency between markers is shown. An active marker button allows you to move one or the other marker, or both together. Press the Set Active Marker(s) to activate the second marker. Use the up and down arrow keys to move the marker a few grid lines above the bookmark created above			
Compress the file and play the frequency change to the chart	 lect 20 mm/sec in the Effective Speed pull-down box. ess the Goto Specified Item button ess Bookmark button ess Goto Bookmark ess Enable / Disable Chart Playback button so that it has a red X through it ess the Run / Pause Playback button un the chart until you have the change in frequency printed ess Enable / Disable Chart Playback button to stop the chart playback <i>it red X disappears</i>). 			
Exit Virtual Chart file review	Press the Close Review Window button (X in upper right-hand corner)			
Exit Virtual Chart Mode	Press the Home Menu button Press Realtime Setup Press the button next to Virtual Chart (<i>The green checkmark disappears</i>) Press [OK]			

This completes the fourth exercise, Virtual Chart Recording.

7e. Data Capture Recording

Data capture allows capture of high-speed transient waveforms. Data capture happens in the background and does not interrupt realtime recording. Playback yields effective speeds up to 10,000 mm/sec. Data review allows for cursor measurements as well as zoom to review critical parts of the capture. Data capture for the signal input modules must be purchased at time of order.

ACTION	HOW TO
Check your	Press the Home Menu button
Recorder-Workstation	Press Help
for Data Capture option	Press About
1 1	If you have Data Capture, it will list the amount of memory it has (8 MB or 16 MB)
	next to each of the SM2 or SM2D modules.
	Press X to exit the Help About window
	Press X to exit the Menu window

Continue with the two-grid pattern and channel setup made with the Realtime Recording exercise above.

ноw то

ACTION Control Panel Configuration

Confirm that your Control Panel has the following buttons for Data Capture:



If any of the buttons are not shown, use the steps below to add them. See "Helpful Hints when working with Control Panels" on Page 6 of this guide.

To add Capture Setup button	Choose Home Menu button >> Custom Control Panel >> Make New Panel Press one of the empty cells to highlight where the button will be placed Press Capture Press Capture Setup To add another button, skip the next step and highlight where it will be placed. Press [OK] to accept the control panel
To add Capture Start button	Choose Home Menu button >> Custom Control Panel >> Make New Panel Press one of the empty cells to highlight where the button will be placed Press Capture Press Capture Start To add another button, skip the next step and highlight where it will be placed. Press [OK] to accept the control panel
To add Manual Trigger button	Choose Home Menu button >> Custom Control Panel >> Make New Panel Press one of the empty cells to highlight where the button will be placed Press Trigger Press Manual Trigger <i>To add another button, skip the next step and highlight where it will be placed.</i> Press [OK] to accept the control panel
To add Manual Abort button	Choose Home Menu button >> Custom Control Panel >> Make New Panel Press one of the empty cells to highlight where the button will be placed Press Trigger Press Manual Abort <i>To add another button, skip the next step and highlight where it will be placed.</i> Press [OK] to accept the control panel
To add Trigger Indicator button	Choose Home Menu button >> Custom Control Panel >> Make New Panel Press one of the empty cells to highlight where the button will be placed Press Trigger Press Trigger Indicator Press [OK] to accept the control panel
To add Open Split Screen Review button	Choose Home Menu button >> Custom Control Panel >> Make New Panel Press one of the empty cells to highlight where the button will be placed Press Realtime Control Press Open Split Screen Review Press [OK] to accept the control panel













Enable and Set Up	Press the Home Menu button			
Data Capture	Press Capture Setup			
	Press the gray button next to Slot A Enable (<i>A green checkmark appears</i>)			
	Press the Base Filename box (A keyboard pops up)			
	Type in Learning about Data Capture			
	Note: You can use upper and lower case letters. There is a clear button to erase text.			
	Press [OK]			
	Press the Effective Chart Speed pull-down box			
	Select 1000 mm/s (12000 Hz)			
	Press the Capture Size pull-down box			
	Select 32000 mm/s (2.67 sec)			
	In the Trigger Position section, press the button next to % Pre-Trigger			
	(A green checkmark appears)			
	Press the number box. A keypad pops up. Press the digits "25", then [OK]			
	In the Re-Arm Type section, press the button next to Manual Re-Arm			
	(A green checkmark appears)			
	In the Memory Stacking section, press the button next to Enable Memory Stacking			
	(A green checkmark appears)			
	Press [OK] to exit Data Capture Setup			
~				
Setup Trigger	Press Trigger			
	Press Trigger Setup (The Trigger Setup Menu appears).			
	Press Amplitude Window OR (yellow highlight)			
	Press Amplitude Trigger Setup button (The Trigger Window appears).			
	Highlight A01 – Waveform A01			
	Press the Upper column			
	Press New Value A keypad pops up. Press the digits "0.25", then [OK]			
	Press the Lower column			
	Press New Value A keypad pops up. Press the digits "0.25", then [OK]			
	Press the Window column			
	Press Outside			
	Press the OR column			
	Press Yes			
	Press [OK]			
	Confirm trigger parameters by pressing the Trigger Equation button			
	A yellow highlight box will appear with "Amplitude window $OR = A01$ and manual"			
	Press [OK] to exit Trigger Setup Menu and return to realtime display			
Enchla Manual Abart				
Enable Manual Abort	Press the Home Menu button			
	Press Trigger			
	Press Abort Setup			
	Press Manual (the color of Manual will change to a yellow highlight)			
	Press [OK]			
Prenare for Data Canture	Confirm that your signal into channel 1 is $\pm/-1$ Volt sine wave 10 Hz. Signal span is			
Tiepare for Data Capture	5 yolts and the zero is in the center of the channel. Turn off the signal generator			
	5 voits and the zero is in the center of the enamer. Furn on the signal generator			
Test for Trigger	When the trigger condition is not met, the Trigger Indicator button will be graved out			
Condition	When the trigger condition is not the Trigger Indicator will highlight vellow			
Condition	Turn the signal generator on and off and observe the Trigger Indicator			
	Turn off the generator			
	run on the generator.			
Start the Data Capture	Press the Canture Start button			
	The status bar at the top of the control panel indicates capture of pre-trigger data			
	Turn on the signal generator			
	The status bar shows post-trigger data is capture.			
	The trigger indicator button is highlighted.			
	6 · · 6 · · · · · ·			
Derform enother	Turn off the signal generator			
Data Capture	Press the Canture Start button. Turn on the signal generator			
Dum Cupture	Tress are capture start outon. Turn on the signal generator			

Save the Data Capture files	 Before you can review data capture files, they must be saved from the high-speed RAM on the SM2 or SM2D module to the system disk. Press the Capture Setup button At the bottom of the Capture Setup window, data capture record status is given. "2-Unsaved Segments" flashes advising that they should be saved or deleted. Press the Save Now button Press [OK] to exit the Capture Setup menu Wait for the Data Captures to be saved before going to the next step.
Review the Data Capture	Press the Open Split Screen Review button Highlight one of the files just created Press [OK] <i>The trigger point is shown in the center of the review window.</i>
Perform Amplitude Measurements	Select Amplitude in the Measurement pull-down box <i>A marker appears and the amplitude at that point is shown in the information box.</i> Use the up and down arrow keys to move the marker a few grid lines below the trigger point
Perform Time & Frequency Measurements	Select Time-Freq in the Measurement pull-down box Another marker appears and the time and frequency between markers is shown. An active marker button allows you to move one or the other marker, or both together. Press the Set Active Marker(s) to activate the second marker. Use the up and down arrow keys to move the marker a few grid lines above the trigger point
Print the area between the markers	Press the More Functions button located to the left of the exit button <i>Additional functions are shown</i> . Press the Print Data Capture button Press *Everest (markers) <i>Observe the trigger mark printed across the page</i> .
Scroll through the Data Capture file	The Waveform Trackbar shows the Data Capture file for quick access to points of interest. The trigger point is indicated by a brown triangle. Drag the highlighted area to move about the waveform.
Expand the File View	Press the Expand File button several times and note the expansion / compression factor as you do so.
Exit Data Capture File Review	Press the X located in the upper right hand corner of the review screen <i>This completes the fifth and final exercise, Data Capture recording.</i>



8. POWERING DOWN

When the power switch is set to the off position or if AC power is removed, the Recorder-Workstation begins the power down sequence. The green LED next to the power switch will either be solid green or flicker during the power down sequence. It is **very important** not to turn the power switch back to the on position during the power down stage. The Recorder-Workstation must be allowed to complete the power down sequence to insure proper operation.

Throughout the setup of the Recorder-Workstation, you can use the on-line Help to guide you. Under many of the menus are additional choices for more advanced capabilities.

Should you require additional assistance, you can contact our Technical Support Department toll-free at 800-343-4039 or by e-mail: techserv@astromed.com

APPENDIX A

SIGNAL INPUT WIRING

SM2 / SM3 & SM2D / SM3D

SM2 / SM3 Signal Module – Wiring Information

Analog Input:

SM2 / SM3 have BNC connectors for analog inputs.

Note: All signal grounds on BNC input connectors are tied together.

SM2D / SM3D Signal Module – Wiring Information

Analog Input:

Pin	Description	Pin	Description
1	+ Channel 1	13	+ Channel 5
2	- Channel 1	14	- Channel 5
3	Ground	15	Ground
4	+ Channel 2	16	+ Channel 6
5	- Channel 2	17	-Channel 6
6	Ground	18	Ground
7	+ Channel 3	19	+ Channel 7
8	- Channel 3	20	- Channel 7
9	Ground	21	Ground
10	+ Channel 4	22	+ Channel 8
11	- Channel 4	23	- Channel 8
12	Ground	24	Ground
		25	Not Used

Notes: SM2D / SM3D have a 25-pin, male D-shell connector for analog inputs. All signal grounds on analog input connector are tied together.

Event Marker Input for SM2 / SM2 & SM2D / SM3D:

Pin	Description
1	Event 1
2	Event 2
3	Event 3
4	Event 4
5	Event 5
6	Event 6
7	Event 7
8	Event 8
9	Ground

Note: Connector is a 9-pin, female D-shell for event (discrete) inputs.